



door slam stopper

Uncompromising on safety, only high performance materials are used in the manufacture of the Fred range. This Door Slam Stopper is engineered from top quality SEBS and ABS.



Important!

Fred wants to keep you and your family safe but we need you to do your bit. Read this instruction carefully before mounting and using this device. The child protective function of the device may be affected if you do not follow the instructions. Keep the instructions for future reference.

Step by step video fitting guides at **www.fredsafety.co.uk**

Step by step installation guide

We recommend that the Door Slam Stopper is fitted on the top horizontal edge of the door. If it is fitted on the vertical edge of the door, ensure it is high up well out of reach of your children.

Recommended Usage



The Door Slam Stopper (A) is designed to fit interior doors with a thickness of 30-45mm.

Important: With the Door Slam Stopper in place, finger-traps will be reduced, but not eliminated on the hinge side. Please ensure children do not insert fingers into hinged edges of doors.

Use on top of doors



Clamp the Door Slam Stopper onto the top edge of your door, at least 35cm from the hinged side. This is the preferred position as the door remains wider open, reducing finger-traps.



Important: Your door/hinge could be damaged if the Door Slam Stopper is positioned closer than 35cm to the hinged edge.

Use on side of doors



The Door Slam Stopper can also be fitted on the opening side of the door. In this position, the door will not be held as wide open, so more finger-traps at the hinge could be present. When fitting to the side, position the Door Slam Stopper high, out of reach of children.

1 How to store



Fred SecureHold™ adhesive is instantly strong. It cannot be repositioned when placed incorrectly so test each step first, without exposing the adhesive. Before installation, clean and dry the surface with a 50:50 solution of water plus white vinegar or surgical spirit.

2



Remove the protective layer from the EZ-Dock™ (B).





Push the sticky side firmly into place for 30 seconds. Leave for 24 hours prior to first use.

4



Simply pull the Door Slam Stopper off the door and press it onto the EZ-Dock™ when not in use.

5



Fire Officers recommend that all doors are closed at night as a precaution. While the door is shut, keep the Door Slam Stopper on the EZ-Dock™ and you will always know where it is.

To permanently remove



Use a blunt knife to gently prise the EZ-Dock™ off the wall when you no longer need it, and rub away any residual adhesive.

⚠ Safety Warnings

- ATTENTION! This product acts as a deterrent but cannot replace adult supervision. Never leave children unattended. This is not a toy, do not leave the Slam Stopper where it is accessible to young children.
- Check the product regularly to ensure it is safe to use and working correctly.
- WARNING Replace the device if any part is broken, torn or missing.
- This product is designed to offer protection for children up to the age of approximately 24 months.
- If your child has learnt how to remove the product, stop depending on it immediately.
- $\bullet \ \textbf{Caution!} \ \textbf{Do not use at night.} \ \textbf{Fire officers recommend that all doors are kept shut at night.}$
- Never use a Door Slam Stopper on fire doors.

Other Important Information

- Care instructions: Wipe with a damp cloth. Do not immerse this product in water.
- Caution! Fred SecureHold™ adhesive may cause damage to some surfaces. We accept no liability or responsibility for damage or defects arising from the use of the adhesive on any furniture or surfaces.
- Occasionally, you will need to use a 50:50 mix of water plus either white vinegar or surgical spirit to remove
 adhesive residue. This mix could cause damage to some surfaces, so please test its use on a discreet area first.
 We do not accept any liability for damage so caused.
- Claims against warranties or guarantees must be arranged through your retailer, seller or trader. Proof of original purchase is required.

Carefully designed, top quality products for protecting against falls, finger-traps, electric shocks, burns and access to dangerous objects are what Fred is all about.

FRDS. Important! Effective when used in accordance with these instructions. This Slam Stopper only protects the handle side of the door - for full protection, use an alternative device on the hinged side. Not for use on Fire Doors. Position the Slam Stopper high, out of reach of children. Complies with EN16654:2015 & REACH. Fred* is a registered trademark of its distributor Cheeky Rascals Ltd, Liss Mill, Mill Road, GU33 7BD, UK help@cheekyrascals.co.uk. Design and manufacturing by Safe and Care Co. ApS, Sellerup Vangvej 32, DK-7080 Børkop, Denmark. Registered Design. Made in China.